



**LOAD RESTRAINT OF SLABS**



**DO NOT USE WEBBING STRAPS TO RESTRAIN THIS PRODUCT**

**SLABS RESTRAINED IN ACCORDANCE WITH THE ABOVE, COMPLY WITH THE PERFORMANCE STANDARDS OUTLINED IN THE LOAD RESTRAINT GUIDE**

**POSITION THE SLABS TO ENSURE AXLE WEIGHTS ARE NOT EXCEEDED**  
**POSITION THE SLABS EVENLY ACROSS THE DECK**  
**USE AT LEAST ONE 8MM TRANSPORT CHAIN FOR EVERY 5 TONNES OF SLABS**  
**FOR SINGLE SLABS 9 TONNE & OVER, USE AT LEAST THREE 8MM TRANSPORT CHAINS**  
**TENSION THE CHAIN TO 750 KG MIN. USING A SUITABLE TENSIONER**  
**USE RUBBER STRIPS UNDER CHAIN EACH SIDE TO PROTECT SLAB SURFACE**  
**PLACE AT LEAST ONE CHAIN OVER SLABS AT OR NEAR EACH DUNNAGE POSITION**  
**USE EXTREME CARE IF USING A 'DOG'**  
**TRANSPORT CHAIN SHOULD COMPLY WITH AS/NZS 4344**

 <p><b>LOADSAFE</b> LOADSAFE AUSTRALIA PTY. LTD.</p>	<p>ACN 068 828 133</p> <p>DATE OCT 2004</p> <p>APPROVED  R. LARSEN BEMBECH</p>	<p>THE INFORMATION HEREON IS THE PROPERTY OF TOMAGO ALUMINIUM COMPANY PTY LIMITED ANY COPYING, TRANSMITTAL TO OTHERS AND USE, EXCEPT THAT FOR WHICH IT IS LOANED IS PROHIBITED WITHOUT WRITTEN PERMISSION.</p>	 <p><b>TOMAGO ALUMINIUM</b> Company Pty Limited ALUMINIUM LOAD RESTRAINT STANDARDS SLABS</p> <p>ACN 001 062 226 AS/NZS 9101 062 226</p>
---	---	--	--

Due to safety risks associated with the use of 'overcentre' loadbinders (dog and chain), this type of load restraint equipment must not be used.